



Customer Service Call us at:

1-877-844-5510 or

email: info@thebadgerhead.com

SAFETY INFORMATION

Warning! - **Before each use and periodically during use,** inspect your trimmer head and cut medium for damage or disrepair. Do not continue use if anything is damaged or broken.

Warning! - Always wear safety glasses or goggles and gloves when using a weed trimmer. Wear long pants and sturdy shoes and do not wear loose clothing. Avoid hearing loss by wearing hearing protection. Eye protection meeting ANSI Z87 (or your national standard) is recommended. **Failure to wear proper eye protection can result in blindness.**

Warning! - Do Not Exceed 10,000 RPM.

Warning! - If excessive vibration occurs during use or if the trimmer head becomes damaged, stop using immediately.

Warning! - Prior to starting, inspect the work area and pick up all loose objects that could be thrown by the weed trimmer. **Always operate the weed trimmer with the cutting head below the waist** and avoid overreaching with a weed trimmer.

Warning! - Keep bystanders and pets away at a minimum of 50 feet during operation.

Warning! - Keep feet and hands away from trimmer head while operating.

Warning! - Never change cutting mediums while the engine is running.

Warning! - Follow all guidelines of weed trimmer manufacturer for safe operation and never operate trimmer without proper OEM guards and safeties in place.

Warning! - Only use hardware supplied with your unit.

Warning! - Use only cut medium and/or attachments designed for use in weed trimmers and follow manufacturers guidelines for proper use.


Warning! - Trimmer head rotates at high speed during use. Contact with solid foreign objects such as rocks, may cause objects to ricochet in direction of operator or bystanders. Striking such objects could damage the trimmer head and/or cut medium.

Thrown objects, including damaged head or cut medium, may result in serious or fatal injury to the operator or bystander. Use trimmer head equipped with proper cut medium only for cutting grass and similar material.

ADAPTER PLATE (optional):

The BadgerHead Adapter Plate is an optional attachment which when installed on the Badger-Head, allows the attachment of common rotary accessories.

To install the adapter plate, insert adapter plate post into two (2) post guides on main body and fully seat.



Next, locate 1/4 serrated lock nuts and install on threaded post using 1/4 wrench to tighten.



Rotary attachments which use a 3/8" thread can attach directly to the adapter plate bolt. To attach accessory, simply twist on until seated. **(May require use of left-hand screw. See Note.)**

NOTE: Depending on manufacturer and model, weed trimmers turn either clockwise (CW) or counterclockwise (CCW).



Direction is defined by rotation observed when holding trimmer in normal operating manner as shown CW in picture. For units with CCW rotation, the Flat

head, left-hand screw provided with kit, must be installed to prevent accessory from coming loose and potentially falling off during use. Units with CW rotation do not require additional screw.

CCW rotating trimmers must use provided Flat head screw as shown. This is a left-hand thread. To tighten, turn CCW.



Important

- Always Use Eye and Body Protection while operating power equipment.
- Guide Pins should remain installed at all times to prevent an opportunity for debris to collect at pin contact area.
- Use of specific rotary accessories is at user's discretion and risk.
- Consider Trimmer rotation as some rotary attachments are designed to operate in specific rotary direction.
- Follow guidelines of Weed Trimmer manufacturer for safe operation.
- Failure to follow instructions could result injury.